

X5 Quickstart Guide






TABLE OF CONTENTS

1	Introduction.....	4
2	Security Features	5
3	System Configuration Examples.....	6
3.1	Client/Server Configuration (JMobile Client on Handheld).....	6
3.2	JMobile Runtime on Handheld.....	7
4	Product Reference Information.....	8
4.1	Keypad Shortcuts in X5 Handheld	8
4.2	Pressing Multiple Keys in X5 Handheld	8
4.3	Simplified Wiring Diagram.....	8
5	Device Publisher.....	10
5.1	Redirect Device Publisher Information to the PLC/Controller	11
5.2	Avoid Using a Full Modbus Server Stack for Device Publisher	12
6	Quickstart Guide.....	13
6.1	Base Station.....	13
6.2	X5 Wireless Handheld	15
7	Further Steps with X5.....	17
7.1	Use VNC Client for Easier Access to BS and Handheld.....	17
7.2	Connect Base Station to a Controller/PLC.....	17
7.3	Quality of Pairing.....	17
7.4	Manually Flashing Pairing Lamp.....	18
7.5	Importing/Exporting UID Lists	18
7.5.1	Exporting UID List.....	18
7.5.2	Importing UID List.....	18





1 Introduction

You will find in this document the minimal information required to set-up a working X5 sample system.

These notes are not a replacement for the X5 User Manual and JMobile User Manual.

X5 is based on Linux BSP version 1.3.xxx.

Products based on BSP 1.3.xxx must be programmed with JMobile version 4.1.0.xxx or higher.

These products are NOT compatible with earlier versions of JMobile.



2 Security Features

This platform comes built-in security features.

The system now requires that you are logged-in to do any action with the BSP.

Products are configured at manufacturing time with two users:

admin

user

Each user has own password to validate the access.

At first power-up the system will require users to choose a new password replacing the default one.

The message you will see is:

Authentication/Users

Default password detected – please choose a more secure one. NOTE: system will reboot upon completion.

At Exor we have established the following conventions for passwords in use internally purely for testing purposes:

User: admin

Password: Exor123@

User: user

Password: Exor123@

If you are receiving a device that has been pre-programmed at Exor, these are the credentials we have entered.

Access the system as “admin” whenever you need to change any property in System Settings.

Please note that without authenticating as a valid user you cannot even access System Settings or Start-up in your X5 devices.

When entering passwords for the **first time** you will not be required to enter the old (default) password.

You can change BSP passwords at later time; use the option “Authentication” in System Settings for this. Remind that in this case you will have to enter the old password to be able to change to a new one.

3 System Configuration Examples


3.1 Client/Server Configuration (JMobile Client on Handheld)

Benefits:

- complex PLC communication protocols are not using wireless band
- in case of configurations with multiple base stations and a single handheld, the handheld is automatically loading the HMI program when connecting to the Base Station
- JMobile application running on Base Station can continue operation and data acquisition also when the handheld is not connected

Weaknesses:

- depending on JMobile project complexity, Client/Server connection may take some time






3.2 JMobile Runtime on Handheld

Benefits:

- Fast starting of JMobile application on handheld

Weaknesses:

- extra band load on wireless network. Performance to be evaluated
- PLC protocol requires routing. Performance to be evaluated.





4 Product Reference Information

4.1 Keypad Shortcuts in X5 Handheld

F2 and F5 Keep pressed for about 2 seconds	Switch on/Switch off handheld
K1 and K4	Start safety pairing application


4.2 Pressing Multiple Keys in X5 Handheld

Keypad handler in X5 handheld supports a maximum of 2 keys pressed at the same time. If more than 2 keys are pressed at the same time, the handler will return a no-key pressed status.

Only available with BSP version 1.3.291 or higher

4.3 Simplified Wiring Diagram

Simple monitor board for test purposes.



Note that 24 Vdc connection at connector X6 is required also when Selector outputs are not used.



5.1 Redirect Device Publisher Information to the PLC/Controller


You can automatically redirect the information produced by Device Publisher to the Controller/PLC connected to the Base Station.

This will ensure the most efficient transfer of time-critical information directly from the handheld to the Controller/PLC.

Please note that to do so the Controller/PLC must have a Modbus TCP server configured for operating in UDP mode.

Addressing of Device Publisher information is given above.

Figure shows the diagram of the system you will be setting.



1	Connect to Base Station using a browser and open System Settings. Remind that you will be asked to enter credentials.												
2	Settings/Services Open Router/NAT/Port forwarding Define a Port forwarding rule associated the port used by the Modbus protocol of the Device Publisher <div style="border: 1px solid #ccc; padding: 5px; margin: 5px 0;"> Port Forwarding Rules <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Enabled</th> <th>Name</th> <th>Source Interface</th> <th>Source Port</th> <th>Device IP</th> <th>Device Port</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;"><input checked="" type="checkbox"/></td> <td>Dev-Pub</td> <td>wlan0</td> <td style="text-align: center;">502</td> <td style="text-align: center;">10.1.34.131</td> <td style="text-align: center;">502</td> </tr> </tbody> </table> </div> Note that the "Device IP" address will have to be replaced with the actual IP address of the controller you have connected to the Base Station	Enabled	Name	Source Interface	Source Port	Device IP	Device Port	<input checked="" type="checkbox"/>	Dev-Pub	wlan0	502	10.1.34.131	502
Enabled	Name	Source Interface	Source Port	Device IP	Device Port								
<input checked="" type="checkbox"/>	Dev-Pub	wlan0	502	10.1.34.131	502								
3	Note that Modbus in UDP mode is only sending out datagrams and does not expect response from the server. The protocol in Device Publisher does not establish communication sessions and does not provide error information, even in case the server is not present.												



5.2 Avoid Using a Full Modbus Server Stack for Device Publisher

Device Publisher is using Modbus TCP protocol in UDP mode to send X5 device information. Port number 502, standard assignment to Modbus TCP and UDP, is used as default. The software application uses only one data packet to send information using Modbus Function Code 16, Write Multiple Registers. Dimensions of the Modbus packet are fixed. Data section is 28 bytes. Modbus in UDP mode does not expect a response from the server receiving the data.

The format of the UDP packet in Device Publisher is shown in figure (produced with WireShark).

```
> Frame 29979: 83 bytes on wire (664 bits), 83 bytes captured (664 bits) on
  Ethernet II, Src: Netgear_68:b3:df (8c:3b:ad:68:b3:df), Dst: Dell_b1:54:8
    Destination: Dell_b1:54:8c (c8:f7:50:b1:54:8c)
      Address: Dell_b1:54:8c (c8:f7:50:b1:54:8c)
        ....0. .... = LG bit: Globally unique address (fa
        ....0. .... = IG bit: Individual address (unicast)
      Source: Netgear_68:b3:df (8c:3b:ad:68:b3:df)
      Type: IPv4 (0x0800)
    Internet Protocol Version 4, Src: 10.1.34.28, Dst: 10.1.32.153
    User Datagram Protocol, Src Port: 39892, Dst Port: 502
    Modbus/UDP
  Modbus
    .001 0000 = Function Code: Write Multiple Registers (16)
    Reference Number: 0
    Word Count: 14
    Byte Count: 28
    Register 0 (UINT16): 1
    Register 1 (UINT16): 36089
    Register 2 (UINT16): 2298
    Register 3 (UINT16): 6547
    Register 4 (UINT16): 374
    Register 5 (UINT16): 0
    Register 6 (UINT16): 0
    Register 7 (UINT16): 0
    Register 8 (UINT16): 0
    Register 9 (UINT16): 0
    Register 10 (UINT16): 32767
    Register 11 (UINT16): 0
    Register 12 (UINT16): 32
    Register 13 (UINT16): 23140
```

The payload of Device Publisher starts at byte with offset 49; see it highlighted in yellow in figure.

The byte sequence of the payload is:


Modbus Function Code	10
Start/End Address	00 00 00 0e
Byte Length	1c
Version	00 01
Counter	8c f9
Elapsed	08 fa 19 93 01 76 00 00
Key map	00 00 00 00 00 00 00 00
Wheel	7f ff
Pot 0	00 00
Pot 1	00 20
Wi-Fi level	5a
Battery charge level	64

X5 data area is highlighted in yellow. Values are shown as example.

6 Quickstart Guide

Objective of this guide is setting-up a simple working configuration for demonstration purposes. Configuration is shown in figure.

Connect one LED indicator to the Pairing output in X4 of the base station. It will be required to complete the safety pairing procedure between BS and X5 handheld.





Ethernet network IP addressing may obviously change based on available network metric.

6.1 Base Station

You must complete setup of Base Station first as you will be able to access handheld using Base Station as the access point.

1	<p>Find IP address assignment of Base Station eth1. This is a process common to all Exor eXware7xx devices. Switch on Base Station (BS). Allow about one minute to complete boot phase. Connect eth1 to network. Find network address of eth1 using service in JMobile Studio Manage Target Run> Manage Target> Board The device may have been assigned an Auto-IP address or may have received an address from a DHCP server.</p>
2	<p>Connect to device System Settings using a computer running a browser. https://ipaddress/machine_config System is protected by default.</p>



	<p>In case the product has been pre-programmed at Exor before leaving the factory, credentials are: user=admin password=Exor123@</p>																																			
3	<p>Settings/Localisation: Enter Country Code = Italy (or the country where you are)</p>																																			
4	<p>Settings/Network: Assign fixed IP address and mask to eth1 Enable Wi-Fi and Safety Network Choose Wi-Fi channel</p>  <p>Network Interfaces</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Label</th> <th>MAC</th> <th>DHCP</th> <th>Address</th> <th>Netmask</th> <th>Gateway</th> </tr> </thead> <tbody> <tr> <td>eth0</td> <td>WAN</td> <td>00:30:d8:09:95:c9</td> <td>Enabled</td> <td>10.1.34.134</td> <td>255.255.255.0</td> <td>10.1.34.253</td> </tr> <tr> <td>eth1</td> <td>LAN1</td> <td>00:30:d8:09:95:ca</td> <td>Disabled</td> <td>192.168.11.110</td> <td>255.255.255.0</td> <td>192.168.11.1</td> </tr> <tr> <td>eth1 nat1to1.0</td> <td>ALIAS</td> <td></td> <td></td> <td>192.168.11.150</td> <td></td> <td></td> </tr> <tr> <td>wlan0</td> <td>WIFI</td> <td>24:7d:4d:6f:78:55</td> <td>Disabled</td> <td>172.27.72.1</td> <td>255.255.255.0</td> <td></td> </tr> </tbody> </table> <p>Wireless Networking</p> <p>Regulatory Domain: IT</p> <p>Interface Name: wian0</p> <p>Enabled: Yes</p> <p>Safety WiFi Network: Yes</p> <p>Channel: 38 (5190 MHz) - INDOOR ONLY</p> <p>State: COMPLETED ✓</p> <p>Connected Stations: 1</p>	Name	Label	MAC	DHCP	Address	Netmask	Gateway	eth0	WAN	00:30:d8:09:95:c9	Enabled	10.1.34.134	255.255.255.0	10.1.34.253	eth1	LAN1	00:30:d8:09:95:ca	Disabled	192.168.11.110	255.255.255.0	192.168.11.1	eth1 nat1to1.0	ALIAS			192.168.11.150			wlan0	WIFI	24:7d:4d:6f:78:55	Disabled	172.27.72.1	255.255.255.0	
Name	Label	MAC	DHCP	Address	Netmask	Gateway																														
eth0	WAN	00:30:d8:09:95:c9	Enabled	10.1.34.134	255.255.255.0	10.1.34.253																														
eth1	LAN1	00:30:d8:09:95:ca	Disabled	192.168.11.110	255.255.255.0	192.168.11.1																														
eth1 nat1to1.0	ALIAS			192.168.11.150																																
wlan0	WIFI	24:7d:4d:6f:78:55	Disabled	172.27.72.1	255.255.255.0																															
5	<p>Settings/Services Define a NAT rule to prepare direct access to the X5 handheld Open Router/NAT/Port forwarding</p>  <p>Router / NAT / Port forwarding</p> <p>Enabled: <input checked="" type="checkbox"/></p> <p>Port Forwarding Rules</p> <p>None</p> <p>1:1 NAT Rules</p> <table border="1"> <thead> <tr> <th>Enabled</th> <th>Name</th> <th>Source Interface</th> <th>Source IP</th> <th>Device IP</th> <th>Port or Range (empty or P1 or P1-Pn)</th> </tr> </thead> <tbody> <tr> <td><input checked="" type="checkbox"/></td> <td>X5 wireless</td> <td>eth1</td> <td>192.168.11.150</td> <td>172.27.72.2</td> <td></td> </tr> </tbody> </table> <p>Device IP is fixed. Source IP is the address assigned to BS in the network where it is attached. Note that this corresponds to assigning a fixed IP address to X5 wireless handheld.</p>	Enabled	Name	Source Interface	Source IP	Device IP	Port or Range (empty or P1 or P1-Pn)	<input checked="" type="checkbox"/>	X5 wireless	eth1	192.168.11.150	172.27.72.2																								
Enabled	Name	Source Interface	Source IP	Device IP	Port or Range (empty or P1 or P1-Pn)																															
<input checked="" type="checkbox"/>	X5 wireless	eth1	192.168.11.150	172.27.72.2																																



	Warning: make sure the value entered for “Source IP” is not the same as real IP address assigned to the physical Ethernet port specified as “Source Interface”.
6	Settings/Services Enable SSH Server with autostart Enable VNC Server with autostart
7	Load a simple project file to BS using JM Studio. The sample project should include: System Variables protocol configured for Xbase device Modbus TCP Server protocol configured in UDP mode (“use UDP/IP”) Tags as needed
8	Connect a VNC client to BS to check operation of JMobile runtime with the project file you have just loaded.
9	Connect a VNC client to the address of the handheld as defined at step 5.

6.2 X5 Wireless Handheld

You must have completed configuration described in previous chapter to proceed with handheld.

1	Switch on the handheld. Wait for boot phase to complete. When asked to start the pairing procedure, exit and return to startup menu.
2	Prepare an update package containing “JMobile Client” using JM Studio Install this package to the handheld using a USB flash drive Add the software to the device start-up list.
3	Install “Device Publisher” software application using a USB flash drive Add the software to the device start-up list.
4	Start System Settings Use touchscreen for operation. System is protected by default. In case the product has been pre-programmed at Exor before leaving the factory, credentials are: user=admin password=Exor123@
4	Settings/Localisation: Enter Country Code = Italy (or the country where you are)
5	Settings/Network: Enable Safety Wi-Fi



6	Settings/Device Publisher Enable Device Publisher. Use default properties.
7	Connect to X5 Wireless device System Settings using a computer running a browser. The IP address is the one defined with the NAT rule in BS settings https://ipaddress/machine_config System is protected by default. Credentials are user=admin password=Exor123@
8	Settings/Services Enable SSH Server with autostart Enable VNC Server with autostart
9	Start the Pairing application pressing the key combination K1-K4.
10	Select the device you want to pair with. The first time you open the Pairing procedure the list of devices will appear empty. Create one new entry in the pairing list pressing the button "Add" to start the process. You will use the UID number printed on the BS module to identify the BS you want to connect. The UID (Unique Identification) number can also be found in the System/Info page of System Settings in Base Station.
11	Start the pairing procedure following the instructions appearing on screen. Note that to proceed with this process you must have a lamp attached to the pairing output of the BS (connector X4, pin 3). At the successful completion of the pairing procedure, the lamp in the Emergency Stop button will turn on. The E-Stop button will become "red". At this point the safety channel is active. Pressing the Enabling button or Emergency button you will hear the relays switching in BS to match the status of safety devices in the handheld.



7 Further Steps with X5

7.1 Use VNC Client for Easier Access to BS and Handheld

The use of a VNC client running on your computer is suggested to improve your testing experience with X5.

Using VNC you will have the possibility to access screen information in Base Station. Additionally, it will make more convenient for you to access screen information in the X5 handheld.

To use VNC you must enable the VNC service in System Settings/Services.

Make sure you enable VNC service both in BS and in handheld.

To access information in the handheld you must have set the appropriate NAT rule in BS.

Any VNC client compatible with the standard will work.

RealVNC has been tested and proved to work fine.

7.2 Connect Base Station to a Controller/PLC

1	Using the sample JMobile project file created for the Quickstart step, add one additional communication protocol dedicated to controller communication and create required tags.
2	Monitor communication activity using X5 handheld. Additionally, you can directly checky operation of the Base Station connecting with VNC client.

7.3 Quality of Pairing

X5 Safety channel connects the Safety Module in X5 wireless handheld to the Safety Module in BS.

Pairing can be sustained only if the wireless connection guarantees a sufficient level of service.

An indication of the quality of the connection service is available in the screen of the pairing application.

The indication has 5 levels, each associated to a different color. Desired level of optimal operation of the system is the maximum (all 5 bars shown).



There are two factors that may adversely affect quality of connection regarding Safety channel:

- level of Wi-Fi signal; it depends on the distance between antenna of BS and wireless handheld and on the presence/geometry of obstacles that may affect RF signal propagation
- level of occupation of the selected Wi-Fi channel due to the presence of other devices.

Only available with BSP version 1.3.291 or higher.



7.4 Manually Flashing Pairing Lamp

In configurations including multiple systems controlled by X5, it may be useful for operators to easily have an indication of what BS station is currently paired with a certain handheld.

This is the purpose of the “Flash” function available in the Pairing screen.

Pressing the Flash button results in the pairing lamp flashing with a cycle of about 3 Hz for a duration of 4 seconds.

Only available with BSP version 1.3.291 or higher.

7.5 Importing/Exporting UID Lists

The UID List import/export function has the purpose of:

- simplify the creation of log UID lists
- backing-up the content of UID lists
- copying UID lists from one X5 wireless handheld to another.

Managing UID Lists require a USB Flash drive attached to one of the USB ports in the X5 Wireless handheld.

Only available with BSP version 1.3.291 or higher

7.5.1 Exporting UID List

1	Create an empty file called “autoexec.sh” (file length 0 bytes) in the root of a USB Flash drive
2	Create an empty file called “x5bs.get” (file length 0 bytes) in the root of a USB Flash drive
3	Insert the Flash drive in one of the USB ports of X5 handheld
4	Cycle the power of X5 handheld
5	The file “x5bs.get” now contains the list of UID entries copied from X5 handheld. Format of the list is comma-separated values.

Format of file:

UID, description,

UID, description,

...

7.5.2 Importing UID List

1	Create an empty file called “autoexec.sh” (file length 0 bytes) in the root of a USB Flash drive
2	Create an empty file called “x5bs.conf” (file length 0 bytes) in the root of a USB Flash drive
3	Insert the Flash drive in one of the USB ports of X5 handheld
4	Cycle the power of X5 handheld
5	The content of file “x5bs.conf” has been copied to the UID list in X5 handheld. Format of the list is comma-separated values.

Note that if in the root of the USB Flash drive there is both a file “x5bs.conf” and a file “x5bs.get”, then priority goes to the export procedure.