

- 1

CHECK:

Check the correct drive type, check suitable motor type & info
- 2

PREPARE:

Correct tools, suitable mounting location, weather protection
- 3

MOUNT:

Mechanical mounting
- 4

CONNECT:

Power & Control connections
- 5

CHECK:

Final check of everything before operation
- 6

POWER ON
- 7

COMMISSION

the drive parameters
- 8

OPERATE

and check everything is as intended

WARNING! The Optidrive should ONLY be installed by a qualified electrician.

NOTE This guide does not provide detailed installation, safety or operational instructions. See the Optidrive E3 IP66 Outdoor User Manual for complete information.

Unpack and check the drive. Notify the supplier and shipper immediately of any damage.

1

CHECK

Identifying the Drive by Model Number

Each drive can be identified by its model number, as shown in the table below.

ODE	-	3	-	1	2	0021	-	1	F	1	B	-	01	Single Phase Output
Product Family														
Generation														
Frame Size														
Input Voltage		1 = 110 – 115 2 = 200 – 240 4 = 380 – 480												
		No. Of Input Phases												
		Output Current x 10												
		IP Rating A = IP66 Non Switched B = IP66 Switched												
		Dynamic Brake Transistor 1 = Not Fitted 4 = Internal Transistor												
		Filter Type 0 = No Filter F = Internal EMC Filter												

2

PREPARE

Prepare the Mounting Location

The Optidrive must be mounted in a vertical position only.

Installation should be on a suitable flat, flame resistant surface. Do not mount flammable material close to the drive.

Refer to Technical Data and ensure the chosen mounting location is within the drive specification.

The mounting location should be free from vibration.

Do not mount the drive in any area with excessive humidity, corrosive airborne chemicals or potentially dangerous dust particles.

Avoid mounting close to high heat sources.

The drive must not be mounted in direct sunlight. If necessary, install a suitable shade cover.

The mounting location must be free from frost.

Do not restrict the flow of air through the drive heatsink. The drive generates heat which must be naturally allowed to dissipate. Correct air clearance around the drive must be observed.

If the location is subject to wide ambient temperature and air pressure variation, install a suitable pressure compensation valve in the drive gland plate.

NOTE If the drive has been in storage for a period longer than 2 years, the DC link capacitors must be reformed. Refer to online documentation for further information.

3

MOUNT

Mechanical Dimensions

Drive Size	A		D		E		F		G	
	mm	in	mm	in	mm	in	mm	in	mm	in
1	232.0	9.13	189.0	7.44	25.0	0.98	179.0	7.05	161.0	6.34
2	257.0	10.12	200.0	7.87	28.5	1.12	187.0	7.36	188.0	7.40

Drive Size	Weight	
	kg	lb
1	3.1	6.8
2	4.1	9.0

Drive Size	X Above & Below		Y Either Side	
	mm	in	mm	in
1	200	7.87	10	0.39
2	200	7.87	10	0.39

Mounting Bolts		Tightening Torques		
Frame Size		Frame Size	Control Terminals	Power Terminals
All Frame Sizes	4 x M4 (#8)	All Frame Sizes	0.5 Nm (4.5 lb-in)	1 Nm (9 lb-in)

4CONNECT

Cable Selection

- For 1 phase supply, the mains power cables should be connected to L1/L, L2/N.
- For compliance with CE and C Tick EMC requirements, refer to online documentation.
- A fixed installation is required according to IEC61800-5-1 with a suitable disconnecting device installed between the Optidrive and the AC Power Source. The disconnecting device must conform to the local safety code / regulations (e.g. within Europe, EN60204-1, Safety of machinery).
- The cables should be dimensioned according to any local codes or regulations. Maximum dimensions are given in the Rating Tables section of this Quick Start Guide.

Install the Wiring

Drive Size	Cable Gland Sizes		
	Power Cable	Motor Cable	Control Cables
1	M20 (PG13.5)	M20 (PG13.5)	M20 (PG13.5)
2	M25 (PG21)	M25 (PG21)	M20 (PG13.5)

NOTE Typical drive heat losses are approximately 3% of operating load conditions. Above are guidelines only and the operating ambient temperature of the drive MUST be maintained at all times.

Information for UL Compliance

Optidrive E3 is designed to meet the UL requirements. For an up to date list of UL compliant products, please refer to UL listing NMMS.E226333. In order to ensure full compliance, the following must be fully observed.

Input Power Supply Requirements

Supply Voltage	200 – 240 RMS Volts for 230 Volt rated units, + /- 10% variation allowed. 240 Volt RMS Maximum.
Frequency	50 – 60Hz + / - 5% Variation
Short Circuit Capacity	All drives are suitable for use on a circuit capable of delivering not more than 100kA maximum short-circuit Amperes symmetrical with the specified maximum supply voltage when protected by Class J fuses.

Mechanical Installation Requirements

All Optidrive E3 units are intended for installation within controlled environments which meet the condition limits shown in the Environment section of this Quick Start Guide.

The drive can be operated within an ambient temperature range as stated in the Environment section of this Quick Start Guide.

For IP66 (Nema 4X) units, installation in a pollution degree 2 environment is permissible.

Electrical Installation Requirements

Incoming power supply connection must be according to the Incoming Power Connection section of this Quick Start Guide.

Suitable power and motor cables should be selected according to the data shown in Rating Tables section of this Quick Start Guide and the National Electrical Code or other applicable local codes.

Motor Cable	90°C Copper must be used.
-------------	---------------------------

Power cable connections and tightening torques are shown in the Mechanical Dimensions section of this Quick Start Guide.

Integral Solid State short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the national electrical code and any additional local codes. Ratings are shown in the Rating Tables section of this Quick Start Guide.

Transient surge suppression must be installed on the line side of this equipment and shall be rated 480Volt (phase to ground), 480 Volt (phase to phase), suitable for over voltage category iii and shall provide protection for a rated impulse withstand voltage peak of 2.5kV.

UL Listed ring terminals / lugs must be used for all bus bar and grounding connections.

General Requirements

Optidrive E3 provides motor overload protection in accordance with the National Electrical Code (US).

Where a motor thermistor is not fitted, or not utilised, Thermal Overload Memory Retention must be enabled by setting P-60 = 1.

Where a motor thermistor is fitted and connected to the drive, connection must be carried out according to the information shown in the Motor Thermistor Connection section of the Quick Start Guide.

UL rated ingress protection ("Type") is only met when cables are installed using a UL recognized bushing or fitting for a flexible conduit system which meets the required level of protection ("Type").

For conduit installations the conduit entry holes require standard opening to the required sizes specified per the NEC.

Not intended for installation using rigid conduit system.

Control Terminal Wiring

- All analog signal cables should be suitably shielded. Twisted pair cables are recommended.
- Power and Control Signal cables should be routed separately where possible, and must not be routed parallel to each other.
- Signal levels of different voltages e.g. 24 Volt DC and 110 Volt AC, should not be routed in the same cable.
- Maximum control terminal tightening torque is 0.5Nm.
- Control Cable entry conductor size: 0.05 – 2.5mm² / 30 – 12 AWG.

Control Terminal Connections

Switched Units: May use the built in control switch and potentiometer, or external control signals connected to the control terminals.

Non-Switched Units: Require external control signals to be connected to the control terminals.

Switched Units: Default functions of the control switches

Switch Position	POT	Notes
		Factory Default Configuration. Run Forward or Reverse with speed controlled from the Local POT.
Run Forward	STOP	Run Forward
STOP	Run Forward	Sets the output frequency

NOTE Other functions are possible, please refer to the online documentation for additional information.

Using the Control Terminals

1	2	3	4	5	6	7	8	9	10	11
+24 VDC	DI1	DI2	DI3 AI2	+10 VDC	DI4 AI1	OV	A0	OV	RL1	RL2
No.	Purpose				Function					
1	+24VDC 100mA Output				24 VDC Output					
2	DI1 Digital Input 1				Function defined by P-12 & P-15. See below for further info					
3	DI2 Digital Input 2									
4	DI3 Digital Input 3/ AI2 Analog Input 2									
5	+10VDC 5mA Output				10 VDC Output for external potentiometer					
6	DI4 Digital Input 4/ AI1 Analog Input 1				Function defined by P-12 & P-15. Signal format selected by P-16					
7	0VDC Common									
8	AO Analog Output				Function selected by P-25. See Parameter List					
9	0VDC Common									
10	RL1 Output Relay				Function defined by P-18. See Parameter List					
11	RL2 Output Relay									

Connection Example

Factory Default Functions

No.	Description	
DI1	0/1	Open : Stop Closed : Run
DI3	Analog Speed Reference / Preset Speed	Open : Speed Reference set by Analog Speed Reference Closed : Speed Reference set by Preset Speed 1 (P-20)
AI1	Analog Speed Reference Input	Sets the Speed Reference NOTE For Switched units, the internal port is selected by default in P-16. For Non-switched units, an external port or 0 - 10 V reference may be connected. Other signal types may also be used, set P-16 to the correct format.

NOTE Additional functions are possible, refer to the online documentation for further information.

Motor Thermistor Connection

Where a motor thermistor is to be used, it should be connected as follows:

Control Terminal Strip	Additional Information
	Compatible Thermistor: PTC Type, 2.5kΩ trip level. <ul style="list-style-type: none">Use a setting of P-15 that has Input 3 function as External Trip, e.g. P-15 = 3. Refer to online documentation for further details.Set P-47 = "Ptc-eh"

5CHECK






6POWER ON

7 COMMISSION






Operation

Managing the Keypad







The drive is configured and its operation monitored via the keypad and display.

	NAVIGATE	Used to display real-time information, to access and exit parameter edit mode and to store parameter changes.
	UP	Used to increase speed in real-time mode or to increase parameter values in parameter edit mode.
	DOWN	Used to decrease speed in real-time mode or to decrease parameter values in parameter edit mode.
	RESET /STOP	Used to reset a tripped drive. When in Keypad mode is used to Stop a running drive.
	START	When in keypad mode, used to Start a stopped drive or to reverse the direction of rotation if bi-directional keypad mode is enabled.







Operating Displays

		
Drive Stopped / Disabled	Drive is enabled / running, display shows the output frequency (Hz)	Press the Navigate key for < 1 second. The display will show the motor current (Amps)
		
Press the Navigate key for < 1 second. The display will show the motor power (kW)	If P-10 > 0, pressing the Navigate key for < 1 second will display the motor speed (RPM)	



Changing Parameters

		
Press and hold the Navigate key > 2 seconds	Use the up and down keys to select the required parameter	Press the Navigate key for < 1 second
		
Adjust the value using the Up and Down keys	Press for < 1 second to return to the parameter menu	Press for > 2 seconds to return to the operating display



Read Only Parameter Access

		
Press and hold the Navigate key > 2 seconds	Use the up and down keys to select P-00	Press the Navigate key for < 1 second
		
Use the up and down keys to select the required Read Only parameter	Press the Navigate key for < 1 second to display the value	Press and hold the Navigate key > 2 seconds to return to the operating display

Resetting Parameters

	
To reset parameter values to their factory default settings, press and hold Up, Down and Stop buttons for > 2 seconds. The display will show "P-dEF"	Press the Stop key. The display will show "Stop"

Resetting a Fault

	
Press the Stop key. The display will show "Stop"	

8 OPERATE

Parameters

Standard Parameters

Par.	Description	Min	Max	Default	Units												
P-01	Maximum Frequency/Speed Limit	P-02	500.0	50.0 (60.0)	Hz/ RPM												
P-02	Minimum Frequency/Speed Limit	0.0	P-01	20.0	Hz/ RPM												
P-03	Acceleration Ramp Time	0.00	600.0	5.0	s												
P-04	Deceleration Ramp Time	0.00	600.0	5.0	s												
P-05	Stopping Mode/ Mains Loss Response	0	3	0	-												
	<table><tr><th>Setting</th><th>On Disable</th><th>On Mains Loss</th></tr><tr><td>0</td><td>Ramp to Stop (P-04)</td><td>Ride Through (Recover energy from load to maintain operation)</td></tr><tr><td>1</td><td>Coast</td><td>Coast</td></tr><tr><td>2</td><td>Ramp to Stop (P-04)</td><td>Fast Ramp to Stop (P-24), Coast if P-24 = 0</td></tr></table>	Setting	On Disable	On Mains Loss	0	Ramp to Stop (P-04)	Ride Through (Recover energy from load to maintain operation)	1	Coast	Coast	2	Ramp to Stop (P-04)	Fast Ramp to Stop (P-24), Coast if P-24 = 0				
Setting	On Disable	On Mains Loss															
0	Ramp to Stop (P-04)	Ride Through (Recover energy from load to maintain operation)															
1	Coast	Coast															
2	Ramp to Stop (P-04)	Fast Ramp to Stop (P-24), Coast if P-24 = 0															
P-07	Motor Rated Voltage	0	250/500	230/400	V												
P-08	Motor Rated Current	Drive Rating Dependent			A												
P-09	Motor Rated Frequency	10	500	50 (60)	Hz												
P-10	Motor Rated Speed	0	30000	0	RPM												
P-11	Low Frequency Torque Boost	0.0	Drive Dependent		%												
P-12	Primary Command Source	0	9	0	-												
	0: Terminal Control 1: Uni-directional Keypad Control 2: Uni-directional Keypad Control 3: Modbus Network Control 4: Modbus Network Control		5: PI Control 6: PI Analog Summation Control 7: CAN Control 8: CAN Control 9: Slave Mode														
	NOTE When P-12 = 1, 2, 3, 4, 7, 8 or 9, an enable signal must still be provided at the control terminals, digital input 1.																
P-14	Extended Menu Access code	0	65535	0	-												

Extended Parameters

Par.	Description	Min	Max	Default	Units
P-15	Digital Input Function Select	0	17	0	-
P-16	Analog Input 1 Signal Format	See Below		U0-10	-
U 0-10 : Unidirectional, External 0 – 10Volt reference / pot R 0-20 : External 0 – 20mA signal L 4-20 : External 4-20mA signal, trip on loss r 4-20 : External 4 – 20mA signal L 20-4 : External 20 – 4mA signal, trip on loss r 20-4 : External 20 – 4mA signal U 10-0 : External 10 – 0 Volt signal I n-Pot : Switched units only : Internal pot					
P-18	Output Relay Function Select	0	9	1	-
0: Drive Enabled (Running) 1: Drive Healthy 2: At Target Frequency (Speed) 3: Drive Tripped 4: Output Frequency >= Limit		5: Output Current >= Limit 6: Output Frequency < Limit 7: Output Current < Limit 8: Analog Input 2 > Limit 9: Drive Ready to Run			
P-20	Preset Frequency / Speed 1	-P-01	P-01	5.0	Hz/RPM
P-21	Preset Frequency / Speed 2	-P-01	P-01	25.0	Hz/RPM
P-22	Preset Frequency / Speed 3	-P-01	P-01	40.0	Hz/ RPM
P-23	Preset Frequency / Speed 4	-P-01	P-01	P-09	Hz/ RPM
P-24	2nd Ramp Time (Fast Stop)	0.00	600.0	0.00	s
P-25	Analog Output Function Select	0	11	8	-
Digital Output Mode. Logic 1 = +24V DC 0: Drive Enabled (Running) 1: Drive Healthy 2: At Target Frequency (Speed) 3: Drive Tripped Analog Output Mode 8: Output Frequency (Motor Speed) 9: Output (Motor) Current					
		4: Output Frequency >= Limit 5: Output Current >= Limit 6: Output Frequency < Limit 7: Output Current < Limit 10: Output Power 11: Load Current			
P-31	Keypad Start Mode Select	0	7	1	-
0: Minimum Speed, Keypad Start 1: Previous Speed, Keypad Start 2: Minimum Speed, Terminal Enable 3: Previous Speed, Terminal Enable		4: Current Speed, Keypad Start 5: Preset Speed 4, Keypad Start 6: Current Speed, Terminal Start 7: Preset Speed 4, Terminal Start			
P-32	Boost Frequency	0	150	5	s
P-33	Boost Period Duration	0	150	5	s
P-34	Brake Chopper Enable (Not Size 1)	0	4	0	-
0: Disabled 1: Enabled With Software Protection 2: Enabled Without Software Protection 3: Enabled With Software Protection 4: Enabled Without Software Protection					
P-38	Parameter Access Lock	0	1	0	-
0: Unlocked 1: Locked					
P-39	Analog Input 1 Offset	-500.0	500.0	0.0	%
P-40	Index 1: Display Scaling Factor	0.000	16.000	0.000	-
	Index 2: Display Scaling Source	0	3	0	-
P-41	PI Controller Proportional Gain	0.0	30.0	1.0	-
P-42	PI Controller Integral Time	0.0	30.0	1.0	s
P-43	PI Controller Operating Mode	0	1	0	-
0: Direct Operation 1: Inverse Operation 2: Direct Operation, Wake at Full Speed 3: Reverse Operation, Wake at Full Speed					
P-44	PI Reference (Setpoint) Source Select	0	1	0	-
0: Digital Preset Setpoint		1: Analog Input 1 Setpoint			
P-45	PI Digital Setpoint	0.0	100.0	0.0	%
P-46	PI Feedback Source Select	0	5	0	-
0: Analog Input 2 1: Analog Input 1 2: Motor Current		3: DC Bus Voltage 4: Analog 1 – Analog 2 5: Largest (Analog 1, Analog 2)			
P-47	Analog Input 2 Signal Format	-	-	-	U0-10
U 0-10 : Unidirectional, External 0 – 10Volt reference / pot R 0-20 : External 0 – 20mA signal L 4-20 : External 4-20mA signal, trip on loss r 4-20 : External 4 – 20mA signal L 20-4 : External 20 – 4mA signal, trip on loss r 20-4 : External 20 – 4mA signal Ptc-Lh : Motor thermistor					
P-48	Standby Mode Timer	0.0	25.0	0.0	s
P-49	PI Control Wake Up Error Level	0.0	100.0	5.0	%
P-50	User Output Relay Hysteresis	0.0	100.0	0.0	%
P-60	Thermal Overload Retention	0	1	0	-

Technical Data

Environment

Operational ambient temperature range

Enclosed Drives: -10 ... 40°C (frost and condensation free)

Storage ambient temperature range: -40 ... 60°C

Maximum altitude: 2000m. Derate above 1000m: 1% / 100m

Maximum humidity: 95%, non-condensing

Rating Tables

Frame Size	kW	HP	Input Current	Fuse /MCB (Type B)		Maximum Cable Size		Output Current	Recommended Brake Resistance
				Non UL	UL	mm	AWG		
200 - 240 (+ / - 10%) V 3 Phase Input, 3 Phase Output									
1	0.37	0.5	6.0	10	10	8	8	4.3	-
1	0.75	1	9.3	16	15	8	8	7.0	-
1	1.1	1.5	14.0	20	20	8	8	10.5	100

NOTE Cable sizes shown are the maximum possible that may be connected to the drive. Cables should be selected according to local wiring codes or regulations at the point of installation.

Troubleshooting

Fault Code Messages

Fault Code	No.	Description
01-b	01	Brake channel over current
0L-br	02	Brake resistor overload
0-I	03	Output Over Current
I-L-trP	04	Motor Thermal Overload (I2t)
0-volt	06	Over voltage on DC bus
U-volt	07	Under voltage on DC bus
0-t	08	Heatsink over temperature
U-t	09	Under temperature
E-tr iP	11	External trip
SC-ObS	12	Optibus comms loss
FLt-dc	13	DC bus ripple too high
P-LOSS	14	Input phase loss trip
h 0-I	15	Output Over Current
Lh-FLt	16	Faulty thermistor on heatsink
dRtR-F	17	Internal memory fault (IO)
4-20 F	18	4-20mA Signal Lost
dRtR-E	19	Internal memory fault (DSP)
F-Ptc	21	Motor PTC thermistor trip
FAn-F	22	Cooling Fan Fault (IP66 only)
0-hERt	23	Drive internal temperature too high
OUT-F	26	Output fault
RtF-Q2	41	Autotune Fault
SC-F01	50	Modbus comms loss fault
SC-F02	51	CAN comms loss trip

NOTE Following an over current or overload trip (3, 4, 5, 15), the drive may not be reset until the reset time delay has elapsed to prevent damage to the drive.

Please scan the QR code to access the complete User Manual



Or visit bit.ly/E31Pmanuals



82-E361P-IN_V1.00

Invertek Drives Ltd. Offa's Dyke Business Park,
Welshpool, Powys SY21 8JF United Kingdom
Tel: +44 (0)1938 556868 Fax: +44 (0)1938 556869
www.invertekdrives.com