

Modbus & Profinet Quick Guide

NFO Sinus Optimal

Communication using Modbus

Modbus RTU or Modbus ASCII can be used for communication with the inverter. Available communication ports are RS485 (accessible from terminals) and USB type B device port implementing a virtual COM port. For connection and setup of communication parameters, please see Operating and Installation Manual.

The inverter implements a bus slave, and will never transmit data unless transmission is initiated by a bus master. Default station address is 1. The Modbus implementation follows “MODBUS over Serial Line Specification and Implementation Guide V1.02” and “MODBUS APPLICATION PROTOCOL SPECIFICATION V1.1b”, available from <https://www.modbus.org>

Available function codes are:

Code Description

- 03 Read Holding Registers
- 04 Read Input Registers
- 06 Write Single Register
- 16 Write Multiple Registers

Any parameter value and/or data is by default treated as a 16-bit data type, transmitted with most significant byte first (Big Endian). For 32-bit values, the low order 16-bit word is transmitted first, followed by the high order word (i.e. communication is Big Endian on a 16-bit level but Little Endian on a 32-bit level).

The available parameters of the inverter are numbered using an Application Data Interface (ADI) number, starting on 1. Each ADI (parameter index) can contain up to 64 bits of data (2x 32-bit or 4x 16-bit), but most parameter sizes are only 16 bits. Modbus register address start offset for ADI number 1 is 210h (528 in decimal), and each ADI takes up four Modbus register addresses (i.e. next Modbus register base address will be 214h, then 218h, etc).

Default bus master access to Modbus register addresses should be by using the parameter’s base register address (i.e. a register address that is a multiple of 4). The bus master may also choose to access the registers that are located on the in-between addresses (e.g. 211h, 212h and 213h), but this will only be possible if the parameter in question is 32-bit (or 2x 32-bit, 4x 16-bit, etc), and if the parameter itself requires explicit access to a register address that is not aligned with the ADI base address. If bus master makes an illegal register address access, the inverter will reply with a Modbus error code.

For bus master read access, the number of registers to read in each transmission is internally limited to the number of registers used by the ADI in question, i.e. maximum four consecutive registers (if parameter is 64 bits).

Below follows a small selection of parameters that can be accessed from the inverter. A complete list of parameters can be downloaded from www.nfodrives.se Please note that the parameters are always accessed using their Modbus register address, while the ADI number is used only for reference to the parameter in documentation or when using other communication methods than Modbus. The table continues on next page.

| Parameter Name | ADI | Modbus reg. addr | Type | Scaling/ Coding | Remark |
|--------------------------|-----|------------------|--------|---|-----------|
| I-rms (output current) | 120 | 03ECh – 03EDh | SINT32 | mA ($A \times 10^3$) | Read only |
| P-out (output power) | 121 | 03F0h – 03F1h | SINT32 | W ($kW \times 10^3$) | Read only |
| PF (output power factor) | 122 | 03F4h | SINT16 | 1×10^3 | Read only |
| Stator Freq (actual) | 125 | 0400h | SINT16 | Hz $\times 10^1$ | Read only |
| Control Freq (setpoint) | 195 | 0518h | SINT16 | Hz $\times 10^1$ | Read only |
| Rotor Speed (actual) | 22 | 0264h | SINT16 | rpm | Read only |
| Control Speed (setpoint) | 21 | 0260h | SINT16 | rpm | Read only |
| Operating Time | 39 | 02A8h – 02A9h | UINT32 | h $\times 10^2$ (one tick per every 36 s) | Read only |
| Running Time | 40 | 02ACh – 02ADh | UINT32 | h $\times 10^2$ (one tick per every 36 s) | Read only |

| Serial Control Parameters | | | | | |
|----------------------------|-----|-------|--------|--|-----------|
| MODE | 34 | 0294h | UINT16 | 1 = Manual 2 = Auto 3 = Bus | |
| SMODE (Command) | 35 | 0298h | UINT16 | 0 = Stop 081h = Run (from terminal) 101h = Run (from Input setpoint) | |
| Input Freq Setpoint | 124 | 03FCh | SINT16 | Hz × 10 ¹ | |
| Input Speed Setpoint | 20 | 025Ch | SINT16 | rpm | |
| Inverter Status with Ack | 38 | 02A4h | UINT16 | Status code, see description | Read only |
| Inverter Status w/out Ack | 38 | 02A5h | UINT16 | Status code, see description | Read only |
| Alternative Serial Control | | | | | |
| Drive Control | 18 | 0254h | UINT16 | Bit field, see description | |
| Drive Status | 19 | 0258h | UINT16 | Bit field, see description | Read only |

Control from terminals and use Modbus to read status and actual values

If the inverter is controlled from terminals (e.g. run signal, analog input etc.), you can still use the Modbus interface for continuously reading status and actual values. First part of table above contains a selection of readable parameters that could be of interest. For status information, either read the Inverter status which returns a status code, or read the Drive status which reports status using a bit field (both described in following sections).

Control inverter using MODE/SMODE/InverterStatus

To control the inverter (Start/Stop, etc) from a bus interface, the run signal (terminal DIN1) must be active. A common installation would be to strap the run signal to +24V and set parameter Autostart = Off (which is default). Then the inverter will not start by itself when powered on, but it allows control from bus.

First the master shall set the parameter MODE = 3 (bus) to gain control over the inverter. Then it can use SMODE to send a start or stop command. When run command is 081h the inverter will use whatever setpoint is available from the terminals (e.g. analog input, selected fix frequencies, etc), and for run command 101h the setpoint is taken from Input Frequency Setpoint register (in Frequency mode), or Input Speed Setpoint register (in Speed mode).

Status from inverter is reported in parameter Inverter status which can be read from Modbus register addresses 02A4h and 02A5h. Both will reply the same status code, but reading the former will also trigger an acknowledge of alarm or fault condition, if such is active. Table below shows code, corresponding text shown on inverter display, and a short description. The codes in *italic* are merely status, while other codes indicate an alarm or fault condition.

| Code | Text | Description | Code | Text | Description |
|------|-------------------|--|------|--------------------|---|
| 0 | <i>Erased</i> | <i>Error log was erased</i> | 32 | <i>Decel</i> | <i>Inverter is decelerating</i> |
| 1 | GND Fail R | Ground fail detected during run | 33 | <i>Ext Stby</i> | <i>Inverter is ready for run cmd in Auto mode</i> |
| 2 | AC Fail | Mains power error | 34 | <i>Ext Run</i> | <i>Inverter is running in Auto mode</i> |
| 3 | Temp Hi | Too high temperature on heat sink | 35 | <i>Ext Acc</i> | <i>Inverter is accelerating in Auto mode</i> |
| 4 | PTC Temp | Motor temperature sensor trip | 36 | <i>Ext Ret</i> | <i>Inverter is decelerating in Auto mode</i> |
| 5 | Overload | Electronic motor overload trip | 37 | <i>Bus Stby</i> | <i>Inverter is ready for run cmd in Bus mode</i> |
| 6 | Ain Fail | Analog input out of range | 38 | <i>Bus Run</i> | <i>Inverter is running in Bus mode</i> |
| 7 | DC Low | Internal undervoltage warning | 39 | <i>Bus Acc</i> | <i>Inverter is accelerating in Bus mode</i> |
| 8 | DC High | Internal overvoltage warning and trip | 40 | <i>Bus Ret</i> | <i>Inverter is decelerating in Bus mode</i> |
| 9 | GND Fail S | Ground fail detected during stop | 41 | <i>PI Reg</i> | <i>Process regulator is activated at terminal</i> |
| 10 | Imagn Low | Magnetization current too low or too high | 42 | <i>Calibrating</i> | <i>Calibrate procedure is ongoing</i> |
| 11 | Cur Low | Output current too low | 43 | <i>Calibr Done</i> | <i>Calibrate procedure finished</i> |
| 12 | Cur High | Output current too high | 44 | <i>BasicTun Ok</i> | <i>Basic tuning finished</i> |
| 13 | Run Fail | Locked rotor / unable to control motor | 45 | <i>Full Tun Ok</i> | <i>Full tuning finished</i> |
| 14 | Sio Fail | Serial communication timeout | 46 | <i>RsMeas Ok</i> | <i>Stator resistance measurement finished</i> |
| 15 | Bus Fail | Fieldbus communication timeout | 47 | <i>ParCalc Ok</i> | <i>Parameter calculation finished</i> |
| 16 | Tun Fail P | Tuning error, parameter value | 48 | Short Circ | Short circuit error detected |
| 17 | Tun Fail M | Tuning error, measurement | 49 | DC Low Trip | Internal undervoltage trip |
| 18 | RsMeasFail | Tuning error, stator resistance | 50 | SampleTime | Internal error, measurement sample time |

| Code | Text | Description |
|------|-------------|--------------------------------------|
| 19 | TuneCnvFail | Tuning error, calculation |
| 20 | Dsp ComErr | Internal error, communication |
| 21 | Cop Restrtr | Internal error, restart/reboot |
| 22 | Dsp SysErr | Internal error, measurement circuits |
| 23 | Cop ComErr | Internal error, communication |
| 24 | Stop | Inverter is stopped |
| 25 | Wait | Inverter is waiting to become ready |
| 26 | Brake Ch | Brake chopper is operating |
| 27 | Cur Limit | Current limit has been reached |
| 28 | Tuning | Tuning is ongoing |
| 29 | Sleep | Inverter has entered sleep mode |
| 30 | Final Freq | Inverter has reached final frequency |
| 31 | Accel | Inverter is accelerating |

| Code | Text | Description |
|------|--------------|--|
| 51 | Motor Volt | Voltage detected on motor terminals |
| 52 | Unused | Reserved for future use |
| 53 | Not Tuned | Tuning has not been performed |
| 54 | Delay Run | Inverter will start after run delay time |
| 55 | DC Low Ctrl | Internal undervoltage regulation active |
| 56 | DC High Ctrl | Internal overvoltage regulation active |
| 57 | Fact Reset | Parameters was reset to factory default |
| 58 | Cop FwUpdt | Firmware update of co-processor |
| 59 | Dsp FwUpdt | Firmware update of DSP |
| 60 | Gui FwUpdt | Firmware update of GUI |
| 61 | Unused | Reserved for future use |
| 62 | Unused | Reserved for future use |
| 63 | Unused | Reserved for future use |

Control inverter using DriveControl/DriveStatus

As an alternative to the MODE/SMODE method, it's also possible to control the inverter in a fashion more similar to controlling from Profibus/Profinet, using bit field registers for control and status. When using Drive control register, the inverter takes its setpoint from terminals (e.g. analog) or whatever setpoint is selected using other parameters.

Combining control methods MODE/SMODE with Drive control is not allowed as it can render unpredictable behaviour. Also, MODE/SMODE and/or Drive control must not be used when using Profibus, Profinet or any other Anybus CompactCom (fieldbus) module.

Drive control bit field description:

| Bit | Name | Description |
|-----|-----------|---|
| 0 | Switch on | Run command (run signal must be active) |
| 1 | Not used | (value echoed to drive status bit 4) |
| 2 | Not used | (value echoed to drive status bit 5) |
| 3 | Enable | Enable command (must precede Run cmd) |
| 4 | Not used | - |
| 5 | Not used | - |
| 6 | Not used | - |
| 7 | Fault ack | Fault acknowledge on 0 to 1 transition |

| Bit | Name | Description |
|-----|-----------------|---|
| 8 | Not used | - |
| 9 | Not used | - |
| 10 | Not used | - |
| 11 | Not used | - |
| 12 | Not used | - |
| 13 | Not used | - |
| 14 | Bus control cmd | PLC takes control (must precede Enable) |
| 15 | Not used | - |

Drive status bit field description:

| Bit | Name | Description |
|-----|--------------|--|
| 0 | Ready | Ready to receive enable command |
| 1 | Switched on | Inverter output stage is active |
| 2 | Enabled | Enabled, ready to receive run command |
| 3 | Fault active | Fault condition active (may require ack) |
| 4 | Not used | (returns value of drive control bit 1) |
| 5 | Not used | (returns value of drive control bit 2) |
| 6 | Disabled | Run signal not present on terminal DIN1 |
| 7 | Alarm active | Alarm condition active (not require ack) |

| Bit | Name | Description |
|-----|------------------|---|
| 8 | Not used | - |
| 9 | Control from bus | Inverter is in bus mode |
| 10 | Setpoint reached | Output frequency has reached setpoint |
| 11 | Limit active | Inverter has reached current limit |
| 12 | Sleep active | Output is suspended in sleep mode |
| 13 | Stopmode brake | Inverter will brake/ramp to stop |
| 14 | Reverse | Actual rotation is reverse |
| 15 | Stopping | Inverter is decelerating towards a stop |

An example of communication could be that bus master sets the Bus control command bit and then waits for inverter to respond with Control from bus bit in status. Then bus master sets the Enable bit and waits for inverter to respond with Enabled. Now the bus master may start the motor using the Switch on command bit, and inverter will respond with Switched on.

When bus master clears the Switch on bit, inverter will decelerate towards a stop. When fully stopped, the Switched on bit will be cleared and inverter is now ready for a new start command. For other status bits and their meaning, see table above.

Control using Profinet/Profibus

The NFO Sinus Optimal implements Profibus/Profinet Telegram 1 for control/status word and setpoint/actual value. Within the telegram, the parameters are available at following slots (all are 16-bit):

| Slot | Parameter |
|------|--|
| 1 | Profidrive Status word |
| 2 | Profidrive Actual frequency (or speed) |
| 3 | Profidrive Control word |
| 4 | Profidrive Setpoint frequency (or speed) |

Slots are sometimes numbered 0 through 3 instead, but the order of parameters are always as in list above. Actual and Setpoint values are scaled so that the range -8192 – +8192 corresponds to either -50Hz – +50Hz (when in Frequency mode), or -Nnom – +Nnom, e.g. -1500 rpm – +1500 rpm for a four-pole motor (when in Speed mode). A negative number corresponds to reverse rotation. Maximum range is -24576 – +24576 ($\pm 150\text{Hz}$ or $\pm 3 \times N\text{nom}$).

To control the inverter (Start/Stop, etc) from a fieldbus interface, the run signal (terminal DIN1) must be active. A common installation would be to strap the run signal to +24V and set parameter Autostart = Off (which is default). Then the inverter will not start by itself when powered on, but it allows control from bus.

Profidrive control bit field description:

| Bit | Name | Description | Bit | Name | Description |
|-----|-----------|---|-----|-------------|---|
| 0 | Switch on | Run command (run signal must be active) | 8 | Not used | - |
| 1 | Not used | (value echoed to drive status bit 4) | 9 | Not used | - |
| 2 | Not used | (value echoed to drive status bit 5) | 10 | PLC control | PLC takes control (must precede Enable) |
| 3 | Enable | Enable command (must precede Run cmd) | 11 | Not used | - |
| 4 | Not used | - | 12 | Not used | - |
| 5 | Not used | - | 13 | Not used | - |
| 6 | Not used | - | 14 | Not used | - |
| 7 | Fault ack | Fault acknowledge on 0 to 1 transition | 15 | Not used | - |

Profidrive status bit field description:

| Bit | Name | Description | Bit | Name | Description |
|-----|--------------|--|-----|-------------------|---|
| 0 | Ready | Ready to receive enable command | 8 | Not used | - |
| 1 | Operating | Inverter output stage is active | 9 | Control requested | Inverter is in bus mode |
| 2 | Enabled | Enabled, ready to receive run command | 10 | Setpoint reached | Output frequency has reached setpoint |
| 3 | Fault active | Fault condition active (may require ack) | 11 | Limit active | Inverter has reached current limit |
| 4 | Not used | (returns value of drive control bit 1) | 12 | Sleep active | Output is suspended in sleep mode |
| 5 | Not used | (returns value of drive control bit 2) | 13 | Stopmode brake | Inverter will brake/ramp to stop |
| 6 | Disabled | Run signal not present on terminal DIN1 | 14 | Reverse | Actual rotation is reverse |
| 7 | Alarm active | Alarm condition active (not require ack) | 15 | Stopping | Inverter is decelerating towards a stop |

A communication example could be that master sets the PLC control bit and then waits for inverter to respond with Control requested bit in status word. Then bus master sets the Enable bit and waits for inverter to respond with Enabled. Now the bus master may start the motor using the Switch on command bit, and inverter will respond with bit Operating.

When master clears the Switch on bit, inverter will decelerate towards a stop. When fully stopped, the Operating bit will be cleared. Motor is now stopped and inverter is ready for a new start command. For other status bits and their meaning, see table above.

Please contact NFO Drives AB for Profinet/Profibus setup files (gsdml/gsd format).